



City of Fontana

Department of Engineering

WATER EFFICIENT LANDSCAPE WORKSHEET

This worksheet is filled out by the project applicant and it is a required element of the Landscape Documentation Package.

Reference Evapotranspiration (ET_o) 55.6 (San Bernardino)

Hydrozone # /Planting Description ^a	Plant Factor (PF)	Irrigation Method ^b	Irrigation Efficiency (IE) ^c	ETAF (PF/IE)	Landscape Area (sq. ft.)	ETAF x Area	Estimated Total Water Use (ETWU) ^e
Regular Landscape Areas							
				Totals	(A)	(B)	
Special Landscape Areas							
				1			
				1			
				1			
				Totals	(C)	(D)	
						ETWU Total	
						Maximum Allowed Water Allowance (MAWA)^e	

^aHydrozone #/Planting Description

- E.g
 1.) front lawn
 2.) low water use plantings
 3.) medium water use planting

^bIrrigation Method

- overhead spray
 or drip

^cIrrigation Efficiency

- 0.75 for spray head
 0.81 for drip

^dETWU (Annual Gallons Required) =

$Eto \times 0.62 \times ETAF \times Area$
 where 0.62 is a conversion factor that converts acre-inches per acre per year to gallons per square foot per year.

^eMAWA (Annual Gallons Allowed) = $(Eto) (0.62) [(ETAF \times LA) + ((1-ETAF) \times SLA)]$

where 0.62 is a conversion factor that converts acre-inches per acre per year to gallons per square foot per year, LA is the total landscape area in square feet, SLA is the total special landscape area in square feet, and ETAF is .55 for residential areas and 0.45 for non-residential areas.

ETAF Calculations

Regular Landscape Areas

Total ETAF x Area (B)	
Total Area (A)	
Average ETAF B ÷ A	

Average ETAF for Regular Landscape Areas must be 0.55 or below for residential areas, and 0.45 or below for non-residential areas.

All Landscape Areas

Total ETAF x Area (B+D)	
Total Area (A+C)	
Sitewide ETAF (B+D) ÷ (A+C)	

Signed: _____ Date: _____